

Operational manual


for products with LCD screen




Table of contents

1. Enter to the screen menu.....	3
2. Detailed menu.....	3
2.1 - Multi Destination.....	4
2.2 - Format memory.....	4
2.3 - Backlight Saver.....	4
2.4 - Special message off delay.....	4
2.5 - Default page ID.....	5
2.6 - Mode test LCD.....	5
2.7 - Floor address.....	5
2.8 - Door number.....	5
2.9 - Travel info blink delay.....	6
2.10 - Lift ID blink delay.....	6
2.11 - About.....	6

1. Enter to the screen menu

You can enter to your screen menu via the back of the screen with the "Enter" button.



-  DOWN button = Move the arrow down
-  ENTER button = Enter the screen menu and select the section
-  UP button = Move the arrow up


The menu will look like this when you push the "ENTER" button :

```
Vidatech Flash menu
→ Multi Destination
Format memory
Backlight Saver
special message off delay
default page id
mode test lcd
floor address
door number
travel info blink delay
lift id blink delay
about
Exit menu
```


2. Detailed menu

2.1 - Multi destination

Path to access at this setting:




Preview:




2.2 - Format memory

Path to access at this setting:




Preview:




2.3 - Backlight Saver

Path to access at this setting:




Preview:




2.4 - Special message off delay

Path to access at this setting:




Preview:




2.5 - Default page ID

Path to access at this setting and rise up to 34 ID:




Preview:




2.6 - Mode test LCD

Path to access at this setting:




Preview:




2.7 - Floor address

Path to access at this setting and rise up to 253 floor:




Preview:




2.8 - Door number

Path to access at this setting:




Preview:



2.9 - Travel info blink delay

Path to access at this setting:



Preview:


```

Travel info blink delay
Select the blink delay (s)
(0 = no blink)

  2 s
  
```

2.10 - Lift ID blink delay

Path to access at this setting:



Preview:

```

Lift ID blink delay
Select the blink delay (250ms)

  4 250ms
  
```

2.11 - About

Path to access at this setting who is informatif:



Preview:

```

About
Firmware version
Version:9
Press ENTER to return to main menu
  
```